PHONE SUPPORT				OMA CP, Nokia-Ericsson OTA, Openwave, Smart Messaging, MS OTA																							
Vendor	Model	3G	MS OTA	WapSetting - CSD	WapSetting - GPRS	Internet - CSD	Internet - GPRS	MMSSetting - CSD	MMSSetting - GPRS	Bookmarks	WirelessVillage	SyncSetting	DMAccSetting	Mail	Streaming	SipSetting	PocSetting	OMAPocSetting	VoIPSetting	VideoSharing	VisualRadioSetting	VisualRadioPresetGroup	UMASetting	XDMSetting	WLAN
Aiko	51G				x				x																	
Airis	T482		x				x							x												
AK Mobile	AK900			x	x				x																	
Alcatel	ELLEN1			x	x				x																	
Alcatel	ELLEN3			x	x				x																	
Alcatel	MandarinaDuck			x	x				x																	
Alcatel	OT301			x																						
Alcatel	OT311			x																						
Alcatel	OT501			x																						
Alcatel	OT511			x																						
Alcatel	OT512			x																						
Alcatel	OT525			x	x																					
Alcatel	OT526			x	x																					
Alcatel	OT535			x	x																					
Alcatel	OT556			x	x			x	x																	
Alcatel	OT557			x	x			x	x																	
Alcatel	OT557a			x	x			x	x																	
Alcatel	OT565			x	x			x	x																	
Alcatel	OT715			x	x																					
Alcatel	OT735			x	x																					
Alcatel	OT735i			x	x																					
Alcatel	OT756			x	x				x																	
Alcatel	OT757			x	x				x																	
Alcatel	OT-C550			x	x				x																	
Alcatel	OT-C551			x	x			x	x																	
Alcatel	OT-C552			x	x			x	x																	
Alcatel	OT-C560				x				x																	
Alcatel	OT-C630			x	x			x	x																	
Alcatel	OT-C630a			x	x			x	x																	
Alcatel	OT-C635			x	x			x	x																	
Alcatel	OT-C651			x	x				x																	
Alcatel	OT-C652			x	x				x																	
Alcatel	OT-C701			x	x			x	x																	
Alcatel	OT-C750			x	x				x																	
Alcatel	OT-C750a			x	x				x																	
Alcatel	OT-C825			x	x			x	x																	
Alcatel	OT-S319				x				x																	
Alcatel	OT-S621				x				x																	
Alcatel	OT-S850			x	x				x																	
Alcatel	OT-S853			x	x				x																	
Alcatel	OT-S853a			x	x				x																	
Alcatel	OT-V770			x	x			x	x																	
Anycool	D66			x	x				x																	
Asus	J101			x	x			x	x																	
Asus	J102			x	x				x																	
Asus	M303			x	x			x	x																	

Asus	M530W	x	x			x	x							x											
Asus	M930	x					x							x											
Asus	P320		x				x							x											
Asus	P525		x				x							x											
Asus	P526		x				x							x											
Asus	P535		x			x	x							x											
Asus	P750	x	x				x							x											
Asus	V55			x	x				x																
Asus	V66			x	x			x	x																
Asus	V70			x	x			x	x																
Bellwave	A108			x	x			x	x																
BenQ	A500			x	x				x																
BenQ	C30				x				x																
BenQ	S700			x	x				x																
BenQ	S708			x	x				x																
BenQ	S82	x			x																				
BenQ-Siemens	C81			x	x	x	x	x	x			x		x	x										
BenQ-Siemens	CF61			x	x			x	x																
BenQ-Siemens	CL71			x	x			x	x																
BenQ-Siemens	E61			x	x			x	x																
BenQ-Siemens	E71			x	x	x	x	x	x			x		x											
BenQ-Siemens	E81	x		x	x	x	x	x	x						x										
BenQ-Siemens	EF51			x	x			x	x																
BenQ-Siemens	EF81	x		x	x				x					x											
BenQ-Siemens	EL71			x	x	x	x	x	x			x		x	x										
BenQ-Siemens	M81			x	x	x	x	x	x			x		x	x										
BenQ-Siemens	S68			x	x	x	x	x	x			x		x	x										
BenQ-Siemens	S88			x	x			x	x																
BenQ-Siemens	SL91	x		x	x	x	x	x	x					x	x										
Bird	D660			x	x				x																
Brionvega	N7010	x			x		x		x					x	x										
CECT	K808			x	x			x	x																
CECT	T689			x	x				x																
Daxian	X789			x	x				x																
Dbtel	J1			x	x				x																
Dbtel	J6			x	x				x																
Dbtel	J7			x	x				x																
Dbtel	M7			x	x				x																
D-Net	F1			x	x			x	x																
Elson	EL370			x	x				x																
Elson	EL380			x	x			x	x																
Elson	EL399			x	x				x																
Elson	EL470			x	x				x																
Elson	EL480			x	x	x	x		x	x															
Elson	EL490			x	x				x																
Elson	EL510			x	x				x																
Elson	EL520			x	x				x	x															
Elson	EL580			x	x			x	x																
Elson	EL590			x	x				x																
Elson	ESL808			x	x				x																
Elson	SL388			x	x				x																
Elson	SL900			x	x				x																
Ericsson	R320s			x						x															
Ericsson	R320sc			x						x															
Ericsson	R320TITAN			x						x															
Ericsson	R380e			x						x				x											
Ericsson	R380s			x						x				x											

Ericsson	R380sc			x						x				x											
Ericsson	R380world			x						x				x											
Ericsson	R520m			x	x					x				x											
Ericsson	R520mc			x	x					x				x											
Ericsson	R600s			x	x					x															
Ericsson	R600sc			x	x					x															
Ericsson	T20e			x						x															
Ericsson	T20ec			x						x															
Ericsson	T20s			x						x															
Ericsson	T20sc			x						x															
Ericsson	T29s			x						x															
Ericsson	T29sc			x						x															
Ericsson	T39m			x	x					x				x											
Ericsson	T39mc			x	x					x				x											
Ericsson	T65			x	x					x				x											
Ericsson	T66			x						x															
Ericsson	T66mc			x						x															
Ericsson	T68			x	x					x				x											
Ericsson	T68m			x	x					x				x											
Ericsson	T68mc			x	x					x				x											
Eten	G500+		x			x	x							x											
Eten	M500		x			x	x							x											
Eten	M600+		x			x	x							x											
Eten	M700		x				x							x											
Eten	M800	x	x				x							x											
Eten	M800+	x	x				x							x											
Eten	M810	x	x				x							x											
Eten	X500		x			x	x							x											
Eten	X500+		x			x	x							x											
Eten	X600		x				x							x											
Eten	X650		x				x							x											
Eten	X800	x	x			x	x							x											
Eyang	M18			x	x			x	x																
Ezio	E300			x	x																				
Ezio	MB330			x	x			x	x																
Ezio	MP100			x	x			x	x																
Ezio	MP500			x	x			x	x																
Fly	SL300m			x	x				x																
Fujitsu-Siemens	PocketLOOXT810	x	x				x							x											
Fujitsu-Siemens	PocketLOOXT830	x	x				x							x											
General Mobile	DST11			x	x				x																
General Mobile	DST22				x				x																
General Mobile	DSTW1		x				x							x											
General Mobile	G777			x	x			x	x																
Gigabyte	GSmart-i350		x				x							x											
G-Plus	CF901				x				x																
G-Plus	CS502			x	x			x	x																
G-Plus	ES813m			x	x				x																
G-Plus	GB802				x				x																
G-Plus	TS2000			x	x				x																
Gradiente	GF500			x	x				x																
Gradiente	GF760			x	x				x																
Gradiente	GF930			x	x				x																
Gradiente	GF950			x	x				x																
Gradiente	GF970			x	x				x																
Gradiente	GX511				x				x																
Gradiente	VibeGMP-3				x				x																

Grundig	M240			x	x				x																
GSL Xplore	M28			x	x	x	x	x	x	x				x											
Haier	V9000			x	x			x	x																
Hewlett-Packard	iPAQ510		x	x	x	x	x							x											
Hewlett-Packard	iPAQ512		x	x	x	x	x							x											
Hewlett-Packard	iPAQ514		x	x	x	x	x							x											
Hewlett-Packard	iPAQ610	x	x				x							x											
Hewlett-Packard	iPAQ610c	x	x				x							x											
Hewlett-Packard	iPAQ612	x	x				x							x											
Hewlett-Packard	iPAQ612c	x	x				x							x											
Hewlett-Packard	iPAQ614	x	x				x							x											
Hewlett-Packard	iPAQ614c	x	x				x							x											
Hewlett-Packard	iPAQ914	x	x				x							x											
Hewlett-Packard	iPAQh6340		x			x	x							x											
Hewlett-Packard	iPAQhw6515		x			x	x							x											
Hewlett-Packard	iPAQhw6910		x	x	x	x	x							x											
Hewlett-Packard	iPAQhw6915		x	x	x	x	x							x											
Hewlett-Packard	iPAQhw6940		x	x	x	x	x							x											
Hewlett-Packard	iPAQhw6945		x	x	x	x	x							x											
Hewlett-Packard	iPAQhw6960		x	x	x	x	x							x											
Hewlett-Packard	iPAQhw6965		x	x	x	x	x							x											
Hewlett-Packard	iPAQrw6815		x			x	x							x											
Hewlett-Packard	iPAQrw6818		x			x	x							x											
Hewlett-Packard	iPAQrw6828		x			x	x							x											
Hitachi	DMP330			x	x			x	x																
HTC	Alpine		x			x	x							x											
HTC	Amadeus		x	x	x	x	x							x											
HTC	Artemis		x			x	x							x											
HTC	Athena	x	x			x	x							x											
HTC	Blackstone	x	x				x							x											
HTC	BlueAngel		x			x	x							x											
HTC	Breeze	x	x			x	x							x											
HTC	Canary		x				x																		
HTC	Cavalier	x	x				x							x											
HTC	Charmer		x			x	x							x											
HTC	Diamond	x	x				x							x											
HTC	Elf		x			x	x							x											
HTC	Excalibur		x	x	x	x	x							x											
HTC	Feeler		x	x	x	x	x							x											
HTC	Gene	x	x				x							x											
HTC	Herald		x				x							x											
HTC	Hermes	x	x				x							x											
HTC	Himalaya		x			x	x							x											
HTC	Hurricane		x	x	x	x	x							x											
HTC	Jade	x	x				x							x											
HTC	Kaiser	x	x		x		x							x											
HTC	Kii	x	x				x							x											
HTC	Love		x				x							x											
HTC	Magician		x			x	x							x											
HTC	Nike	x	x			x	x							x											
HTC	Oxygen		x				x							x											
HTC	Panda		x				x							x											
HTC	Pharos	x	x				x							x											
HTC	Phoebus	x	x				x							x											
HTC	Polaris	x	x				x							x											
HTC	Prodigy		x			x	x							x											
HTC	Prophet	x	x				x							x											

HTC	Raphael	x	x				x							x											
HTC	Rose	x	x				x							x											
HTC	Sedna	x	x				x							x											
HTC	Sirius	x	x				x							x											
HTC	Sonata		x	x	x	x	x							x											
HTC	Startrek		x			x	x							x											
HTC	Tanager		x				x																		
HTC	Tornado		x				x							x											
HTC	Trinity	x	x			x	x							x											
HTC	Typhoon		x	x	x	x	x							x											
HTC	Universal	x	x			x	x							x											
HTC	Vox		x	x	x	x	x							x											
HTC	Voyager		x			x	x							x											
HTC	Wings	x	x				x							x											
Huawei	U526	x			x				x																
Huawei	U535	x			x				x																
Huawei	U626	x			x				x																
Huawei	U636	x			x				x																
Huawei	V710	x			x				x																
Huawei	V715	x			x									x											
Hyundai	MB-400			new	new			new	new																
Hyundai	MB-910			new	new			new	new																
I-mate	JAQ		x			x	x							x											
I-mate	PDAL		x			x	x							x											
I-mate	SPL		x	x	x	x	x							x											
I-mate	Ultimate6150	x	x				x							x											
I-Mobile	308			x	x				x																
I-Mobile	315			x	x				x																
I-Mobile	318				x				x																
I-Mobile	503			x	x				x																
I-Mobile	508			x	x				x																
I-Mobile	510			x	x				x																
I-Mobile	513			x	x				x																
I-Mobile	518				x				x																
I-Mobile	519				x				x																
I-Mobile	520				x				x																
I-Mobile	600			x	x			x	x																
I-Mobile	606			x	x				x																
I-Mobile	607			x	x				x																
I-Mobile	609			x	x				x																
I-Mobile	610			x	x				x																
I-Mobile	611			x	x				x																
I-Mobile	612			x	x				x																
I-Mobile	613				x				x																
I-Mobile	902			x	x				x																
I-Mobile	903				x				x																
I-Mobile	609i			x	x				x																
I-Mobile	IDEA506			x	x			x	x																
I-Mobile	IDEA602			x	x				x																
I-Mobile	IDEA603			x	x				x																
Innostream	A10			x	x																				
Innostream	I-2000			x	x																				
Innostream	I-2200			x	x																				
Innostream	I-2500			x	x																				
Innostream	I-3000			x	x																				
Innostream	INNO50			x	x																				
Innostream	INNO55			x	x																				

Innostream	INNO75			x	x																				
Innostream	INNO89			x	x																				
Innostream	INNO90			x	x																				
Jasper	S20			x	x			x	x																
Jinpeng	S7180			x	x																				
Kejian	K368			x	x																				
Konka	D163			x	x			x	x																
Konka	D363				x				x																
Konka	M5060				x				x																
Konka	M526				x				x																
K-Touch	A615			x	x				x																
Lenovo	i389				x				x																
Lenovo	P706			x	x																				
LG	500			x	x			x	x																
LG	1400			x	x			x	x																
LG	1500			x	x			x	x																
LG	2000			x	x			x	x																
LG	1300i			x	x			x	x																
LG	510W			x																					
LG	A7150			x	x			x	x																
LG	B2000			x	x			x	x																
LG	B2050			x	x			x	x																
LG	B2070			x	x			x	x																
LG	B2100			x	x			x	x																
LG	B2150			x	x			x	x																
LG	C1100			x	x			x	x																
LG	C1150			x	x			x	x																
LG	C1200			x	x			x	x																
LG	C1300			x	x			x	x																
LG	C2100			x	x			x	x																
LG	C2200			x	x			x	x																
LG	C2500			x	x			x	x																
LG	C3300			x	x			x	x																
LG	C3310			x	x			x	x																
LG	C3320			x	x			x	x																
LG	C3380			x	x			x	x																
LG	C3400			x	x			x	x																
LG	C3600			x	x			x	x																
LG	CU515	x			x		x		x																
LG	F1200			x	x			x	x																
LG	F2100			x	x			x	x																
LG	F2300			x	x			x	x																
LG	F2400			x	x			x	x																
LG	F3000			x	x			x	x																
LG	F7100			x	x			x	x																
LG	G1600			x	x			x	x																
LG	G1610			x	x			x	x																
LG	G1800			x	x			x	x																
LG	G210			x	x			x	x																
LG	G220			x	x			x	x																
LG	G232			x	x			x	x																
LG	G259			x	x			x	x																
LG	G262			x	x			x	x																
LG	G263			x	x			x	x																
LG	G510				x																				
LG	G5300i			x	x			x	x																
LG	G5400			x	x			x	x																

LG	G5410			x	x			x	x																
LG	G5500			x	x			x	x																
LG	G5600			x	x			x	x																
LG	G622			x	x			x	x																
LG	G630			x	x			x	x																
LG	G632			x	x			x	x																
LG	G672			x	x			x	x																
LG	G682			x	x			x	x																
LG	G688			x	x			x	x																
LG	G7020			x	x																				
LG	G7050			x	x			x	x																
LG	G7100			x	x			x	x																
LG	G7110			x	x			x	x																
LG	G850			x	x			x	x																
LG	G912			x	x			x	x																
LG	G920			x	x			x	x																
LG	G932			x	x			x	x																
LG	HB620	x			x		x		x			x	x	x											
LG	HB620T	x			x		x		x			x	x	x											
LG	KB620	x			x		x		x			x	x	x											
LG	KB770	x			x		x	x																	
LG	KC550				x		x		x					x											
LG	KC910	x			x		x		x	x				x											
LG	KE500				x				x																
LG	KE508				x				x																
LG	KE590			x	x			x	x																
LG	KE600			x	x			x	x																
LG	KE608			x	x			x	x																
LG	KE608N			x	x			x	x																
LG	KE770			x	x			x	x																
LG	KE800			x	x			x	x																
LG	KE820			x	x			x	x																
LG	KE850			x	x			x	x																
LG	KE858			x	x			x	x																
LG	KE970			x	x			x	x																
LG	KE990				new				new																
LG	KE990C				new				new																
LG	KE990D				new				new																
LG	KF240				x				x																
LG	KF240C				x				x																
LG	KF240D				x				x																
LG	KF245				x				x																
LG	KF245C				x				x																
LG	KF300				x				x																
LG	KF300C				x				x																
LG	KF310				x		x		x					x	x										
LG	KF350				new		new		new	new				new											
LG	KF350C				new		new		new	new				new											
LG	KF390	x			new				new																
LG	KF510			x	x	x	x		x	x				x											
LG	KF600			x	x				x																
LG	KF700	x			x		x		x	x				x											
LG	KF750	x			x				x																
LG	KF755				new				new																
LG	KF755C				new				new																
LG	KF755D				new				new																
LG	KF900	x			x		x		x	x				x											

LG	KG110				x																			
LG	KG120			x	x																			
LG	KG200			x	x				x															
LG	KG220			x	x			x	x	x														
LG	KG221			x	x			x	x															
LG	KG225			x	x			x	x															
LG	KG228			x	x			x	x															
LG	KG245			x	x			x	x															
LG	KG248			x	x			x	x															
LG	KG280				x				x															
LG	KG290			x	x	x	x		x															
LG	KG296				x				x															
LG	KG300				x				x															
LG	KG320			x	x			x	x															
LG	KG328			x	x			x	x															
LG	KG800			x	x			x	x															
LG	KG810			x	x			x	x															
LG	KG90			x	x			x	x															
LG	KG920			x	x			x	x															
LG	KG928			x	x			x	x															
LG	KG98			x	x			x	x															
LG	KM380				x		x		x					x										
LG	KM380C				x		x		x					x										
LG	KM500				x				x															
LG	KM500C				x				x															
LG	KM501				x				x															
LG	KM710				x		x		x															
LG	KM710C				x		x		x															
LG	KP130			x	x				x															
LG	KP140			x	x				x															
LG	KP170				x				x	x														
LG	KP170B				x				x	x														
LG	KP200				x				x															
LG	KP202				x				x															
LG	KP215			x	x				x															
LG	KP215B			x	x				x															
LG	KP230			x	x	x	x		x															
LG	KP235			x	x				x															
LG	KP265				new				new															
LG	KP265C				new				new															
LG	KP265D				new				new															
LG	KP500				x		x		x	x				x										
LG	KP500Q				x		x		x	x				x										
LG	KS10	x		x	x	x	x		x	x	x	x		x	x	x								
LG	KS20	x	x				x							x										
LG	KS360				x		x		x					x										
LG	KT520	x			x		x		x	x				x										
LG	KT525	x			x		x		x	x				x										
LG	KT610	x			x		x		x		x	x	x	x	x	x								x
LG	KU250	x		x	x				x															
LG	KU311	x		x	x				x															
LG	KU380	x			x		x		x					x										
LG	KU385	x			x		x		x					x										
LG	KU580	x			x		x		x					x										
LG	KU800	x			x				x															
LG	KU950	x			x		x		x					x										
LG	KU970	x			x		x		x					x										

LG	KU990	x			x				x																
LG	L1100			x	x			x	x																
LG	L1150			x	x			x	x																
LG	L1400i			x	x			x	x																
LG	L3100			x	x			x	x																
LG	L5100			x	x			x	x																
LG	L600v	x		x	x				x																
LG	M4410			x	x			x	x																
LG	M6100			x	x			x	x																
LG	ME550C				x				x																
LG	ME550D				x				x																
LG	ME770C			x	x			x	x																
LG	ME970D				x				x																
LG	MG100			x	x			x	x																
LG	MG100A			x	x			x	x																
LG	MG100C			x	x			x	x																
LG	MG105			x	x			x	x																
LG	MG110				x																				
LG	MG110A				x																				
LG	MG110B				x																				
LG	MG120B			x	x																				
LG	MG155				x				x																
LG	MG155C				x				x																
LG	MG180C				x																				
LG	MG180D				x																				
LG	MG185C				x				x																
LG	MG185D				x				x																
LG	MG200				x				x																
LG	MG200C				x				x																
LG	MG210C			x	x			x	x																
LG	MG220C			x	x			x	x																
LG	MG220D			x	x			x	x																
LG	MG225D				x				x																
LG	MG230D				x				x																
LG	MG235C				x				x																
LG	MG280C				x				x																
LG	MG280D				x				x																
LG	MG296C				x				x																
LG	MG296D				x				x																
LG	MG320C			x	x			x	x																
LG	MG320D			x	x			x	x																
LG	MG800C			x	x			x	x																
LG	MG800D			x	x			x	x																
LG	MG810C			x	x			x	x																
LG	MG810D			x	x			x	x																
LG	MS20	x	x				x							x											
LG	MS25	x	x				x							x											
LG	P7200			x	x			x	x																
LG	S5000			x	x			x	x																
LG	S5100			x	x			x	x																
LG	S5200			x	x			x	x																
LG	T5100			x	x			x	x																
LG	U250	x		x	x				x																
LG	U8100	x		x	x																				
LG	U8150	x		x	x																				
LG	U830	x			x		x		x					x											
LG	U8500	x			x				x																

LG	U970	x			x		x		x					x											
LG	U990				x				x																
Linx	M2688			x	x				x																
Mashimaro	M808			x	x				x																
Medion	MD95100			x	x			x	x																
Medion	MD97100			x																					
Mitac	Mio8390		x	x	x	x	x							x											
Mitac	MioA501		x			x	x							x											
Mitac	MioA701		x				x							x											
Mitac	MioA702		x				x							x											
Mitsubishi	M720			x	x			x	x																
Mitsubishi	M900			x	x			x	x																
Modelabs	HummerHT-1			x	x				x	x															
Modelabs	LevisPhone			x	x				x																
Motorola	A1200			x	x			x	x					x											
Motorola	A1600			x	x			x	x																
Motorola	A668			x	x			x	x																
Motorola	A728			x	x																				
Motorola	A760i			x	x																				
Motorola	A768i			x	x																				
Motorola	A780			x	x			x	x																
Motorola	A835	x		x	x			x	x																
Motorola	C168			x	x			x	x																
Motorola	C168i				x				x																
Motorola	C257			x	x			x	x																
Motorola	C261			x	x			x	x																
Motorola	C350			x	x																				
Motorola	C380			x	x			x	x																
Motorola	C381			x	x			x	x																
Motorola	C384			x	x			x	x																
Motorola	C385			x	x			x	x																
Motorola	C390			x	x			x	x																
Motorola	C450			x	x																				
Motorola	C550			x	x																				
Motorola	C650			x	x			x	x																
Motorola	C651			x	x			x	x																
Motorola	C698P			x	x			x	x																
Motorola	C975	x		x	x			x	x																
Motorola	C980	x		x	x			x	x																
Motorola	E1			x	x			x	x																
Motorola	E1000	x		x	x			x	x																
Motorola	E1070	x		x	x			x	x																
Motorola	E2			x	x			x	x					x											
Motorola	E375			x	x			x	x																
Motorola	E378i			x	x			x	x																
Motorola	E380			x	x																				
Motorola	E398			x	x			x	x																
Motorola	E550			x	x			x	x																
Motorola	E6			x	x			x	x					x	x										
Motorola	E680			x	x	x	x	x	x																
Motorola	E680i			x	x	x	x	x	x																
Motorola	E770	x		x	x			x	x																
Motorola	E770v	x		x	x			x	x																
Motorola	E8			x	x	x	x	x	x			x		x											
Motorola	EM28				x		x		x																
Motorola	EM30			x	x	x	x	x	x																
Motorola	EM330				x		x		x																

Motorola	K1			x	x			x	x																
Motorola	K3	x			x		x		x			x		x											
Motorola	L2			x	x			x	x																
Motorola	L6			x	x			x	x																
Motorola	L7			x	x			x	x																
Motorola	L72			x	x	x	x	x	x					x											
Motorola	L7e			x	x			x	x																
Motorola	L9			x	x	x	x	x	x					x											
Motorola	MPx200		x	x	x	x	x							x											
Motorola	MPx220		x	x	x	x	x							x											
Motorola	Q8		x			x	x							x											
Motorola	Q9h	x	x				x							x											
Motorola	U3				x				x					x											
Motorola	U6			x	x			x	x																
Motorola	U9			x	x	x	x	x	x						x										
Motorola	U9Jewel			x	x	x	x	x	x																
Motorola	V1050	x		x	x			x	x																
Motorola	V1075	x		x	x			x	x																
Motorola	V1100	x			x									x											
Motorola	V150			x	x																				
Motorola	V175			x	x			x	x																
Motorola	V176			x	x			x	x																
Motorola	V177			x	x			x	x																
Motorola	V180			x	x			x	x																
Motorola	V186			x	x			x	x																
Motorola	V190			x	x			x	x																
Motorola	V191			x	x			x	x																
Motorola	V220			x	x			x	x																
Motorola	V220i			x	x			x	x																
Motorola	V226			x	x			x	x																
Motorola	V235			x	x			x	x																
Motorola	V237			x	x			x	x																
Motorola	V3	x		x	x	x	x	x	x																
Motorola	V300			x	x			x	x																
Motorola	V303			x	x			x	x																
Motorola	V330			x	x			x	x																
Motorola	V360			x	x			x	x																
Motorola	V360v			x	x			x	x																
Motorola	V361			x	x			x	x																
Motorola	V365			x	x			x	x																
Motorola	V3i			x	x	x	x	x	x																
Motorola	V3x	x		x	x	x	x	x	x			x		x											
Motorola	V3xx	x			x		x		x			x		x											
Motorola	V400			x	x			x	x																
Motorola	V400P			x	x			x	x																
Motorola	V500			x	x			x	x																
Motorola	V501			x	x			x	x																
Motorola	V525			x	x			x	x																
Motorola	V535			x	x			x	x																
Motorola	V545			x	x			x	x																
Motorola	V547			x	x			x	x																
Motorola	V550			x	x			x	x																
Motorola	V551			x	x			x	x																
Motorola	V555			x	x			x	x																
Motorola	V6	x			x		x		x			x		x											
Motorola	V600			x	x			x	x																
Motorola	V620			x	x			x	x																

Motorola	V635			x	x			x	x																
Motorola	V690			x	x			x	x																
Motorola	V8			x	x			x	x						x										
Motorola	V80			x	x			x	x																
Motorola	V872			x	x			x	x																
Motorola	V9	x			x		x		x				x	x											
Motorola	V975	x		x	x			x	x																
Motorola	V980	x		x	x			x	x																
Motorola	W206				x				x																
Motorola	W213				x				x																
Motorola	W220			x	x			x	x																
Motorola	W230				x				x																
Motorola	W231				x				x																
Motorola	W270				x				x																
Motorola	W370				x				x																
Motorola	W371				x				x																
Motorola	W375				x				x																
Motorola	W377				x		x		x																
Motorola	W388				x				x																
Motorola	W490			x	x	x	x	x	x					x											
Motorola	W5			x	x	x	x	x	x					x											
Motorola	W510			x	x	x	x	x	x					x											
Motorola	Z10	x		x	x	x	x	x	x		x	x		x											
Motorola	Z3			x	x			x	x					x											
Motorola	Z6			x	x			x	x			x		x	x										
Motorola	Z6c			x	x			x	x			x		x											
Motorola	Z8	x		x	x	x	x	x	x			x		x											
Motorola	ZN200				x				x																
Motorola	ZN5			x	x	x	x	x	x																
MWG	ZincII	x					x							x											
MyPhone	T22Duo				x				x																
Myway	MW200			x	x				x																
Neonode	N2				x				x																
Nokia	1101			x						x															
Nokia	2610				x		x		x	x				x											
Nokia	2626				x		x		x	x	x			x											
Nokia	2630				x		x		x	x	x			x											
Nokia	2650			x	x				x	x															
Nokia	2651			x	x				x	x															
Nokia	2652			x	x				x	x															
Nokia	2660			x	x	x	x		x	x	x			x											
Nokia	2760			x	x	x	x		x	x	x			x											
Nokia	3100			x	x				x	x															
Nokia	3108			x	x				x	x															
Nokia	3120			x	x				x	x															
Nokia	3200			x	x			x	x	x															
Nokia	3220			x	x	x	x		x	x	x	x		x											
Nokia	3230			x	x	x	x		x	x	x	x		x	x		x								
Nokia	3250			x	x	x	x		x	x		x	x	x	x		x								
Nokia	3300			x	x			x	x	x															
Nokia	3330			x						x															
Nokia	3350			x						x															
Nokia	3395			x						x															
Nokia	3410			x						x															
Nokia	3510			x	x					x															
Nokia	3530			x	x			x	x	x															
Nokia	3555	x		x	x	x	x		x																

Nokia	3590			x	x			x	x	x				x											
Nokia	3595			x	x			x	x	x				x											
Nokia	3600			x	x	x	x	x	x	x				x											
Nokia	3610			x						x															
Nokia	3620			x	x	x	x	x	x	x				x											
Nokia	3650			x	x	x	x	x	x	x		x		x											
Nokia	3660			x	x	x	x	x	x	x		x		x											
Nokia	5000				x		x		x	x	x	x	x	x											
Nokia	5070			x	x	x	x		x	x	x	x		x			x								
Nokia	5100			x	x				x	x															
Nokia	5140			x	x	x	x		x	x	x	x		x			x								
Nokia	5200			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	5210			x						x															
Nokia	5300			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	5510			x						x															
Nokia	5700	x		x	x	x	x		x	x	x	x	x	x	x	x	x				x	x			
Nokia	6010			x	x					x															
Nokia	6020			x	x	x	x		x	x		x		x			x								
Nokia	6021			x	x	x	x		x	x		x		x			x								
Nokia	6030				x		x		x	x															
Nokia	6060			x	x	x	x		x	x	x			x											
Nokia	6061			x	x	x	x		x	x	x			x											
Nokia	6062			x	x	x	x		x	x	x			x											
Nokia	6070			x	x	x	x		x	x	x	x		x			x								
Nokia	6080			x	x	x	x		x	x	x	x		x			x								
Nokia	6085			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6086			x	x	x	x		x	x		x		x	x		x								
Nokia	6100			x	x				x	x															
Nokia	6101			x	x	x	x		x	x	x	x		x			x								
Nokia	6103			x	x	x	x		x	x		x		x			x								
Nokia	6108			x	x				x	x															
Nokia	6111			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6125			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6126			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6131			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	6136			x	x	x	x		x	x	x		x	x			x						x		x
Nokia	6151	x		x	x	x	x		x	x		x	x		x		x								
Nokia	6170			x	x	x	x		x	x		x		x	x		x								
Nokia	6200			x	x	x	x		x	x		x		x											
Nokia	6210			x						x															
Nokia	6220			x	x	x	x		x	x	x	x													
Nokia	6230			x	x	x	x		x	x	x	x		x	x										
Nokia	6233	x		x	x	x	x		x	x		x	x	x	x		x								
Nokia	6234	x		x	x	x	x		x	x		x		x	x		x								
Nokia	6250			x						x															
Nokia	6260			x	x	x	x		x	x		x		x	x		x								
Nokia	6263	x			x		x		x																
Nokia	6267	x			x		x		x	x	x	x	x	x	x		x								
Nokia	6270	x		x	x	x	x		x	x				x	x		x								
Nokia	6280	x		x	x	x	x		x	x		x	x	x	x		x			x					
Nokia	6282	x		x	x	x	x		x	x		x		x	x		x								
Nokia	6288	x		x	x	x	x		x	x	x	x	x	x	x		x			x					
Nokia	6290	x			x		x		x	x	x	x	x	x	x	x	x				x	x			
Nokia	6300			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	6301			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6310			x	x					x															
Nokia	6340			x	x					x															

Nokia	6500			x	x					x															
Nokia	6510			x	x					x															
Nokia	6555	x		x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	6590			x	x			x	x	x				x											
Nokia	6600			x	x	x	x		x	x	x	x		x			x								
Nokia	6610			x	x				x	x															
Nokia	6620			x	x	x	x		x	x		x		x	x										
Nokia	6630	x			x		x		x	x	x	x	x	x	x	x	x								
Nokia	6650	x		x	x	x	x		x	x		x													
Nokia	6651	x		x	x	x	x		x	x		x													
Nokia	6670			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6680	x			x		x		x	x	x	x	x	x	x	x	x								
Nokia	6681				x		x		x	x	x	x	x	x	x		x								
Nokia	6682				x		x		x	x	x	x	x	x	x		x								
Nokia	6708			x	x	x	x	x	x	x				x											
Nokia	6800			x	x				x	x		x													
Nokia	6810			x	x	x	x		x	x	x	x		x											
Nokia	6820			x	x	x	x		x	x	x	x		x											
Nokia	6822			x	x	x	x		x	x	x	x		x											
Nokia	7110			x						x															
Nokia	7190			x						x															
Nokia	7200			x	x	x	x		x	x	x	x		x											
Nokia	7210			x	x				x	x															
Nokia	7250			x	x			x	x	x		x													
Nokia	7260			x	x	x	x		x	x	x	x		x											
Nokia	7270			x	x	x	x		x	x	x	x		x			x								
Nokia	7280			x	x	x	x		x	x		x													
Nokia	7360			x	x	x	x		x	x	x	x		x			x								
Nokia	7370			x	x	x	x		x	x	x	x		x	x										
Nokia	7373			x	x	x	x		x	x	x	x	x	x	x										
Nokia	7380			x	x	x	x		x	x		x			x										
Nokia	7390	x		x	x	x	x		x	x	x	x		x	x		x								
Nokia	7600	x		x	x	x	x		x	x		x		x											
Nokia	7610			x	x	x	x		x	x	x	x		x	x		x								
Nokia	7650			x	x	x	x	x	x	x		x		x											
Nokia	7710			x	x	x	x		x	x		x		x											
Nokia	8310			x	x					x															
Nokia	8390			x	x					x				x											
Nokia	8800			x	x	x	x		x	x	x	x		x	x										
Nokia	8801			x	x	x	x		x	x	x	x		x											
Nokia	8850			x						x															
Nokia	8855			x						x															
Nokia	8910			x	x					x															
Nokia	9110			x						x				x											
Nokia	9210			x						x		x		x											
Nokia	9290			x						x				x											
Nokia	9300			x	x	x	x		x	x		x	x	x	x										
Nokia	9500			x	x	x	x		x	x		x	x	x	x										
Nokia	1680Classic				x		x		x	x	x	x	x	x											
Nokia	2600Classic				x		x		x	x	x	x		x											
Nokia	2610b				x		x		x	x				x											
Nokia	2630b				x		x		x	x	x			x											
Nokia	2680Slide				x		x		x	x	x	x	x	x											
Nokia	2680Slideb				x		x		x	x	x			x											
Nokia	2760b			x	x	x	x		x	x	x			x											
Nokia	3100b			x	x				x	x															
Nokia	3109Classic			x	x	x	x		x	x	x	x	x	x	x		x								

Nokia	3110Classic			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	3120b			x	x				x	x															
Nokia	3120Classic	x			x		x		x	x	x	x	x	x	x		x								
Nokia	3200b			x	x			x	x	x															
Nokia	3220b			x	x	x	x		x	x	x			x											
Nokia	3300b			x	x			x	x	x															
Nokia	3500Classic			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	3500Classicb			x	x	x	x		x	x	x	x		x	x		x								
Nokia	3510i			x	x			x	x	x															
Nokia	3555b	x		x	x	x	x		x																
Nokia	3555c	x		x	x	x	x		x																
Nokia	3600Slide				x		x		x	x	x	x	x	x	x		x								
Nokia	3610Fold			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	5070b			x	x	x	x		x	x	x	x		x			x								
Nokia	5130XpressMusic				x		x		x	x				x	x										
Nokia	5140b			x	x	x	x		x	x		x													
Nokia	5140i			x	x	x	x		x	x	x	x		x			x								
Nokia	5200b			x	x	x	x		x	x	x	x		x	x		x								
Nokia	5220XpressMusic				x		x		x	x	x	x	x	x	x		x								
Nokia	5220XpressMusicb				x		x		x	x	x	x		x											
Nokia	5300b			x	x	x	x		x	x	x	x		x			x								
Nokia	5310XpressMusic			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	5310XpressMusicb			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	5320XpressMusic			x	x	x	x		x	x		x	x	x	x	x				x	x	x			
Nokia	5500Sport			x	x	x	x		x	x		x	x	x	x		x				x	x			
Nokia	5610XpressMusic	x			x		x		x	x	x	x	x	x	x		x								
Nokia	5630XpressMusic	x			x		x		x					x	x										x
Nokia	5800XpressMusic	x		x	x	x	x		x		x	x	x	x	x										
Nokia	6020b			x	x	x	x		x	x		x		x			x								
Nokia	6030b				x		x		x	x															
Nokia	6060v			x	x	x	x		x	x	x			x											
Nokia	6070b			x	x	x	x		x	x				x			x								
Nokia	6080b			x	x	x	x		x	x	x	x		x			x								
Nokia	6085h			x	x	x	x		x	x		x		x											
Nokia	6101b			x	x	x	x		x	x	x	x		x			x								
Nokia	6101h			x	x	x	x		x	x	x	x		x			x								
Nokia	6102b			x	x	x	x		x	x	x	x		x			x								
Nokia	6102h			x	x	x	x		x	x	x	x		x			x								
Nokia	6102i			x	x	x	x		x	x		x		x			x								
Nokia	6103b			x	x	x	x		x	x		x		x			x								
Nokia	6110Navigator	x			x		x		x	x	x	x	x	x	x	x	x				x	x			
Nokia	6120Classic	x		x	x	x	x		x	x	x	x	x	x	x	x	x								
Nokia	6121Classic	x		x	x	x	x		x	x	x	x	x	x	x	x	x								
Nokia	6122Classic	x		x	x	x	x		x		x	x		x	x	x					x	x			
Nokia	6124Classic	x		x	x	x	x		x		x	x	x	x	x	x					x	x			
Nokia	6126h			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6131NFC			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	6133b			x	x	x	x		x	x		x		x			x								
Nokia	6133h			x	x	x	x		x	x		x		x			x								
Nokia	6170b			x	x	x	x		x	x		x		x	x		x								
Nokia	6210Navigator	x		x	x	x	x		x	x	x	x	x	x	x	x					x	x			
Nokia	6212Classic	x		x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	6220Classic	x			x		x		x		x	x	x	x	x	x					x	x			
Nokia	6230b			x	x	x	x		x	x		x		x	x										
Nokia	6230i			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6290b	x			x		x		x	x		x	x	x	x		x				x	x			
Nokia	6300b			x	x	x	x		x	x	x	x		x			x								

Nokia	6300i				x		x		x	x	x	x	x	x	x	x			x						x
Nokia	6301b			x	x	x	x		x																
Nokia	6303Classic				new		new		new	new	new	new		new	new										
Nokia	6310i			x	x					x															
Nokia	6340i			x	x					x															
Nokia	6500Classic	x			x		x		x	x		x	x	x	x										
Nokia	6500Slide	x			x		x		x	x	x	x	x	x	x		x								
Nokia	6555b	x		x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	6590i			x	x			x	x	x				x											
Nokia	6600Fold	x			x		x		x		x	x	x	x	x										
Nokia	6600Slide	x			x		x		x	x		x	x	x	x										
Nokia	6610i			x	x				x	x		x													
Nokia	6650T	x		x	x	x	x		x			x	x	x	x										
Nokia	6670b			x	x	x	x		x	x	x	x		x	x		x								
Nokia	6720Classic	x			new		new		new	new															
Nokia	6800a			x	x				x	x															
Nokia	6820a			x	x	x	x		x	x	x	x		x											
Nokia	6820b			x	x	x	x		x	x	x	x		x											
Nokia	6822a			x	x	x	x		x	x	x	x		x											
Nokia	6822b			x	x	x	x		x	x	x	x		x											
Nokia	7070Prism				x		x		x	x	x			x											
Nokia	7100Supernova			x	x	x	x		x	x	x	x	x	x											
Nokia	7210Supernova				x		x		x	x	x	x	x	x	x										
Nokia	7250i			x	x			x	x	x		x													
Nokia	7310Classic			x	x	x	x		x	x	x	x	x	x	x		x								
Nokia	7310Classicb			x	x	x	x		x	x	x	x		x	x		x								
Nokia	7500Prism			x	x	x	x		x	x	x	x	x	x			x								
Nokia	7510Supernova				x		x		x	x	x	x	x	x	x										
Nokia	7510Supernovab				x		x		x	x	x	x	x	x	x										
Nokia	7610b			x	x	x	x		x	x	x	x		x	x		x								
Nokia	7610Supernova				x		x		x	x	x	x	x	x	x		x								
Nokia	7900Prism				x		x		x	x	x	x	x	x	x										
Nokia	8600Luna			x	x	x	x		x	x	x	x	x	x	x										
Nokia	8800Arte			x	x	x	x		x	x	x	x		x	x										
Nokia	8800CarbonArte			x	x	x	x		x	x	x	x		x	x										
Nokia	8800Sirocco			x	x	x	x		x	x	x	x		x	x		x								
Nokia	8910i			x	x			x	x	x															
Nokia	9110i			x						x				x											
Nokia	9210c			x						x		x		x											
Nokia	9210i			x						x		x		x											
Nokia	9300b			x	x	x	x		x	x		x	x	x	x										
Nokia	9300i			x	x	x	x		x	x		x	x	x	x										
Nokia	9500b			x	x	x	x		x	x		x	x	x	x										
Nokia	E50				x		x		x	x		x	x	x	x	x									
Nokia	E51	x		x	x	x	x		x	x	x	x	x	x	x	x	x		x						x
Nokia	E60	x			x		x		x	x		x	x	x	x	x	x		x						x
Nokia	E61	x			x		x		x	x	x	x	x	x	x	x	x		x						x
Nokia	E61i	x			x		x		x	x	x	x	x	x	x	x	x		x						x
Nokia	E62				x		x		x	x	x	x		x	x	x	x								
Nokia	E63	x			x		x		x	x	x	x	x	x	x	x	x		x						x
Nokia	E65	x			x		x		x	x	x	x	x	x	x	x	x		x						x
Nokia	E66	x			x		x		x		x	x	x	x	x	x	x		x		x	x			x
Nokia	E70	x			x		x		x	x	x	x	x	x	x	x	x		x						x
Nokia	E71	x			x		x		x	x	x	x	x	x	x	x	x		x		x	x			x
Nokia	E75	x			new		new		new	new		new	new	new	new	new			new	new					new
Nokia	E90	x			x		x		x	x	x	x	x	x	x	x	x		x						x
Nokia	N70	x			x		x		x	x	x	x	x	x	x	x	x								

Nokia	N71	x			x		x		x	x	x	x	x	x	x	x	x				x	x			
Nokia	N72				x		x		x	x		x	x	x	x		x								
Nokia	N73	x			x		x		x	x	x	x	x	x	x	x	x				x	x			
Nokia	N75	x			x		x		x	x	x	x	x	x	x	x					x	x			
Nokia	N76	x			x		x		x	x	x	x	x	x	x	x	x				x	x			
Nokia	N77	x			x		x		x	x		x	x	x	x						x	x			
Nokia	N78	x			x		x		x		x	x	x	x	x					x	x	x			x
Nokia	N79	x		x	x	x	x		x	x		x	x	x	x	x				x	x	x			x
Nokia	N80	x			x		x		x	x	x	x	x	x	x	x	x		x	x	x	x			
Nokia	N81	x		x	x	x	x		x	x	x	x	x	x	x	x	x		x						x
Nokia	N82	x			x		x		x	x	x	x	x	x	x	x	x		x	x	x	x			x
Nokia	N85	x			x		x		x		x	x	x	x	x	x									x
Nokia	N90	x			x		x		x	x	x	x	x	x	x		x								
Nokia	N91	x			x		x		x	x	x	x	x	x	x	x	x				x	x			
Nokia	N92	x			x		x		x	x	x	x	x	x	x	x	x								x
Nokia	N93	x			x		x		x	x		x	x	x	x	x	x								
Nokia	N93i	x			x		x		x	x		x	x	x	x	x	x				x	x			
Nokia	N95	x			x		x		x	x	x	x	x	x	x	x	x		x		x	x			x
Nokia	N96	x			x		x		x			x	x	x											x
Nokia	N-Gage			x	x	x	x	x	x	x		x		x											
Nokia	N-GageQD					x	x	x	x	x				x											
O2	Ice	x			x				x																
O2	X7Slider			x	x				x																
O2	XDAAtom		x			x	x							x											
O2	XDAAtomLife	x	x			x	x							x											
O2	XDAFlame	x	x			x	x							x											
O2	XDAStealth		x			x	x							x											
Okwap	A323			x	x			x	x																
Okwap	i885				x				x																
Palm	Treo750	x	x			x	x							x											
Panasonic	A210			x	x																				
Panasonic	A500			x	x																				
Panasonic	GD87			x	x			x	x																
Panasonic	GD88			x	x			x	x																
Panasonic	GU87			x	x			x	x																
Panasonic	MX6			x	x			x	x																
Panasonic	MX7			x	x			x	x																
Panasonic	SA6			x	x			x	x																
Panasonic	SA7			x	x			x	x																
Panasonic	SC3			x	x			x	x																
Panasonic	VS2			x	x																				
Panasonic	VS3			x	x			x	x																
Panasonic	VS6			x	x			x	x																
Panasonic	VS7			x	x																				
Panasonic	X11			x				x																	
Panasonic	X200			x	x			x	x																
Panasonic	X300			x	x			x	x																
Panasonic	X400			x	x			x	x																
Panasonic	X60			x	x			x	x																
Panasonic	X66			x	x			x	x																
Panasonic	X68			x	x			x	x																
Panasonic	X70			x	x			x	x																
Panasonic	X700			x	x	x	x		x	x				x											
Panasonic	X701			x	x	x	x		x	x				x											
Panasonic	X77			x	x			x	x																
Panasonic	X800			x	x	x	x		x	x		x		x											
Panasonic	X88			x				x																	

Pantech	PG-1200			x	x				x																
Pantech	PG-1210			x	x				x																
Pantech	PG-1300			x	x				x																
Pantech	PG-1300V			x	x				x																
Pantech	PG-1310V			x	x				x																
Pantech	PG-1400			x	x			x	x																
Pantech	PG-1410			x	x			x	x																
Pantech	PG-1600			x	x			x	x																
Pantech	PG-1610			x	x			x	x																
Pantech	PG-1900			x	x				x																
Pantech	PG-3200			x	x				x																
Pantech	PG-3210			x	x				x																
Pantech	PG-3500			x	x				x																
Pantech	PG-3600			x	x				x																
Pantech	PG-6100			x	x				x																
Pantech	PG-6200			x	x				x																
Pantech	PG-8000			x	x				x																
Pantech	U-4050	x			x				x																
Philips	162			x																					
Philips	355			x	x			x	x																
Philips	362			x	x				x																
Philips	535			x	x				x																
Philips	568			x	x				x																
Philips	639			x	x				x																
Philips	760			x	x				x																
Philips	768			x	x			x	x																
Philips	Xenium9@9c			x	x				x																
Philips	Xenium9@9d			x	x				x																
Philips	Xenium9@9e				x				x																
Philips	Xenium9@9t				x				x																
PhoneOne	M202				x				x																
PhoneOne	M203				x				x																
PhoneOne	M601				x				x																
PhoneOne	M801				x				x																
Phonetech	PT111			x	x			x	x																
Pirelli	DP-L10				x		x																		
Pirelli	DP-SW20		x				x							x											
Prince	MB-660			x	x				x																
Qigi	i55		x				x							x											
Sagem	my213X			x	x			x	x																
Sagem	my300X			x	x			x	x																
Sagem	my301X			x	x			x	x																
Sagem	my302X			x	x			x	x																
Sagem	my400V			x	x			x	x																
Sagem	my400X			x	x			x	x																
Sagem	my401C			x	x			x	x																
Sagem	my401V			x	x			x	x																
Sagem	my401X			x	x			x	x																
Sagem	my411C			x	x			x	x																
Sagem	my411V			x	x			x	x																
Sagem	my411X			x	x			x	x																
Sagem	my500X			x	x			x	x																
Sagem	my501X			x	x			x	x																
Sagem	my511X			x	x			x	x																
Sagem	my600V	x			x		x		x																
Sagem	my600X	x		x	x			x	x																
Sagem	my700X			x	x			x	x																

Sagem	my800C	x		x	x	x	x		x					x											
Sagem	my850V	x		x	x	x	x		x					x											
Sagem	myC-4			x	x			x	x																
Sagem	myC4-2			x	x			x	x																
Sagem	myC5-2			x	x			x	x																
Sagem	myC5-2m			x	x			x	x																
Sagem	myC5-2v			x	x			x	x																
Sagem	myC5-3			x	x			x	x																
Sagem	myE-77			x	x			x	x																
Sagem	myT-55			x	x			x	x																
Sagem	myV-55			x	x			x	x																
Sagem	myV-55a			x	x			x	x																
Sagem	myV-56			x	x			x	x																
Sagem	myV-76			x	x			x	x																
Sagem	myV-8			x	x			x	x																
Sagem	myX5-2			x	x			x	x																
Sagem	myX5-2a			x	x			x	x																
Sagem	myX5-2T			x	x			x	x																
Sagem	myX5-2v			x	x			x	x																
Sagem	myX5-3			x	x			x	x																
Sagem	myX-55			x	x			x	x																
Sagem	myX6-2			x	x			x	x																
Sagem	myX-7			x	x			x	x																
Sagem	myX-8			x	x			x	x																
Sagem	myZ-5			x	x			x	x																
Sagem	V527			x	x			x	x																
Sagem	V533			x	x			x	x																
Samsung	A701	x			x				x																
Samsung	A801	x			x				x					x											
Samsung	B100			x	x				x																
Samsung	B100M			x	x				x																
Samsung	B108			x	x				x																
Samsung	B130			x	x																				
Samsung	B130L			x	x																				
Samsung	B130R			x	x																				
Samsung	B130S			x	x																				
Samsung	B130T			x	x																				
Samsung	B220				x				x																
Samsung	B220B				x				x																
Samsung	B2700				x				x																
Samsung	B300				x		x		x																
Samsung	B308				x		x		x																
Samsung	B320				x				x																
Samsung	B320R				x				x																
Samsung	B500			x	x	x	x		x																
Samsung	B508			x	x	x	x		x																
Samsung	C130			x	x				x																
Samsung	C138			x	x				x																
Samsung	C158			x	x				x																
Samsung	C160				x		x																		
Samsung	C160L				x		x																		
Samsung	C160M				x		x																		
Samsung	C168				x		x																		
Samsung	C170			x	x																				
Samsung	C178			x	x																				
Samsung	C180			x	x	x	x																		
Samsung	C188			x	x	x	x																		

Samsung	C200			x	x				x																
Samsung	C200C			x	x				x																
Samsung	C200N			x	x				x																
Samsung	C200S			x	x				x																
Samsung	C207			x	x				x																
Samsung	C207L			x	x				x																
Samsung	C208			x	x				x																
Samsung	C210			x	x				x																
Samsung	C210C			x	x				x																
Samsung	C210S			x	x				x																
Samsung	C216			x	x				x																
Samsung	C218			x	x				x																
Samsung	C230			x	x				x																
Samsung	C230C			x	x				x																
Samsung	C238			x	x				x																
Samsung	C250			x	x																				
Samsung	C258			x	x																				
Samsung	C260			x	x																				
Samsung	C260L			x	x																				
Samsung	C260M			x	x																				
Samsung	C266			x	x																				
Samsung	C268			x	x																				
Samsung	C300				x				x																
Samsung	C308				x				x																
Samsung	C3110			new	new	new	new		new																
Samsung	C3110C			new	new	new	new		new																
Samsung	C3110H			new	new	new	new		new																
Samsung	C3110Q			new	new	new	new		new																
Samsung	C400			x	x				x																
Samsung	C400L			x	x				x																
Samsung	C408			x	x				x																
Samsung	C420				x				x																
Samsung	C420L				x				x																
Samsung	C421				x				x																
Samsung	C425				x				x																
Samsung	C428				x				x																
Samsung	C450			x	x	x	x		x																
Samsung	C458			x	x	x	x		x																
Samsung	C500				x				x																
Samsung	C500L				x				x																
Samsung	C510			x	x	x	x		x																
Samsung	C510L			x	x	x	x		x																
Samsung	C510V			x	x	x	x		x																
Samsung	C516				x				x																
Samsung	C520			x	x	x	x		x																
Samsung	D410			x	x			x	x																
Samsung	D410C			x	x			x	x																
Samsung	D415			x	x			x	x																
Samsung	D418			x	x			x	x																
Samsung	D428			x	x				x																
Samsung	D488			x	x			x	x																
Samsung	D500			x	x	x	x		x					x											
Samsung	D500C			x	x	x	x		x					x											
Samsung	D500E			x	x	x	x		x					x											
Samsung	D508			x	x	x	x		x					x											
Samsung	D510			x	x				x					x											
Samsung	D510C			x	x				x					x											

Samsung	D520			x	x	x	x		x					x											
Samsung	D528			x	x				x					x											
Samsung	D600			x	x	x	x		x					x											
Samsung	D600E			x	x	x	x		x					x											
Samsung	D606			x	x	x	x		x					x											
Samsung	D608			x	x	x	x		x					x											
Samsung	D720			x	x	x	x		x			x		x	x										
Samsung	D728			x	x	x	x		x			x		x	x										
Samsung	D730			x	x	x	x		x		x	x		x	x										
Samsung	D738			x	x	x	x		x			x		x	x										
Samsung	D780				x		x		x					x											
Samsung	D788				x		x		x					x											
Samsung	D800			x	x	x	x		x					x											
Samsung	D806			x	x	x	x		x					x											
Samsung	D807			x	x	x	x		x					x											
Samsung	D808			x	x	x	x		x					x											
Samsung	D810			x	x				x					x											
Samsung	D820			x	x	x	x		x					x											
Samsung	D828			x	x	x	x		x					x											
Samsung	D828+			x	x	x	x		x					x											
Samsung	D828E			x	x	x	x		x					x											
Samsung	D830			x	x	x	x		x					x											
Samsung	D836			x	x	x	x		x					x											
Samsung	D838			x	x	x	x		x					x											
Samsung	D840			x	x	x	x		x					x											
Samsung	D848			x	x	x	x		x					x											
Samsung	D880			x	x	x	x		x					x											
Samsung	D888			x	x	x	x		x					x											
Samsung	D900			x	x				x					x											
Samsung	D900E				x				x					x											
Samsung	D900i			x	x				x					x											
Samsung	D908			x	x				x					x											
Samsung	D908i			x	x				x					x											
Samsung	D980				x		x		x					x											
Samsung	D988				x		x		x					x											
Samsung	E100			x	x			x	x																
Samsung	E100A			x	x			x	x																
Samsung	E105			x	x			x	x																
Samsung	E108			x	x			x	x																
Samsung	E200			x	x	x	x		x																
Samsung	E200B			x	x	x	x		x																
Samsung	E200E			x	x	x	x		x																
Samsung	E208			x	x	x	x		x																
Samsung	E208B			x	x	x	x		x																
Samsung	E210			x	x	x	x		x																
Samsung	E218			x	x	x	x		x																
Samsung	E230				x				x																
Samsung	E230L				x				x																
Samsung	E250				x				x					x											
Samsung	E250D				x				x					x											
Samsung	E250L				x				x					x											
Samsung	E250V				x				x					x											
Samsung	E251			x	x	x	x		x					x											
Samsung	E2510				new		new		new					new											
Samsung	E2510C				new		new		new					new											
Samsung	E251C			x	x	x	x		x					x											
Samsung	E251L			x	x	x	x		x					x											

Samsung	E256				x				x					x											
Samsung	E258				x				x					x											
Samsung	E300			x	x				x																
Samsung	E308			x	x				x																
Samsung	E310			x	x				x																
Samsung	E310C			x	x				x																
Samsung	E315			x	x				x																
Samsung	E316			x	x				x																
Samsung	E317			x	x				x																
Samsung	E318			x	x				x																
Samsung	E330			x	x			x	x																
Samsung	E330C			x	x			x	x																
Samsung	E330N			x	x			x	x																
Samsung	E330S			x	x			x	x																
Samsung	E335			x	x			x	x																
Samsung	E338			x	x			x	x																
Samsung	E340			x	x				x					x											
Samsung	E340E			x	x				x					x											
Samsung	E348			x	x				x					x											
Samsung	E350			x	x				x																
Samsung	E350E			x	x				x																
Samsung	E351			x	x				x																
Samsung	E351L			x	x				x																
Samsung	E356			x	x				x																
Samsung	E358			x	x				x																
Samsung	E360			x	x			x	x																
Samsung	E360E			x	x			x	x																
Samsung	E368			x	x			x	x																
Samsung	E370			x	x				x					x											
Samsung	E376			x	x				x					x											
Samsung	E378			x	x				x					x											
Samsung	E380			x	x				x					x											
Samsung	E388			x	x				x					x											
Samsung	E390			x	x	x	x		x					x											
Samsung	E398			x	x	x	x		x					x											
Samsung	E400			x	x																				
Samsung	E420				x				x																
Samsung	E428				x				x																
Samsung	E500			x	x				x					x											
Samsung	E500C			x	x				x																
Samsung	E530			x	x				x					x											
Samsung	E530C			x	x				x					x											
Samsung	E538			x	x				x					x											
Samsung	E570			x	x				x																
Samsung	E570L			x	x				x																
Samsung	E570V			x	x				x																
Samsung	E578			x	x				x																
Samsung	E590			x	x	x	x		x					x											
Samsung	E598			x	x	x	x		x					x											
Samsung	E600			x	x			x	x																
Samsung	E600C			x	x			x	x																
Samsung	E608			x	x			x	x																
Samsung	E610			x	x			x	x																
Samsung	E610C			x	x			x	x																
Samsung	E618			x	x			x	x																
Samsung	E620			x	x				x					x											
Samsung	E620C			x	x				x					x											

Samsung	E628			x	x				x					x											
Samsung	E630			x	x			x	x																
Samsung	E630C			x	x			x	x																
Samsung	E630S			x	x			x	x																
Samsung	E635			x	x			x	x																
Samsung	E638			x	x			x	x																
Samsung	E640			x	x				x					x											
Samsung	E648			x	x				x					x											
Samsung	E690			x	x				x					x											
Samsung	E700			x	x			x	x																
Samsung	E700A			x	x			x	x																
Samsung	E708			x	x			x	x																
Samsung	E710			x	x			x	x																
Samsung	E715			x	x			x	x																
Samsung	E720			x	x				x																
Samsung	E720C			x	x				x																
Samsung	E720i			x	x				x																
Samsung	E728			x	x				x																
Samsung	E730			x	x				x					x											
Samsung	E730E			x	x				x					x											
Samsung	E736			x	x				x					x											
Samsung	E738			x	x				x					x											
Samsung	E740			x	x	x	x		x					x											
Samsung	E746				x				x																
Samsung	E748			x	x	x	x		x					x											
Samsung	E750			x	x				x					x											
Samsung	E758			x	x				x					x											
Samsung	E760			x	x				x					x											
Samsung	E768			x	x				x					x											
Samsung	E770			x	x				x					x											
Samsung	E778			x	x				x					x											
Samsung	E780			x	x	x	x		x					x											
Samsung	E786			x	x	x	x		x					x											
Samsung	E788			x	x	x	x		x					x											
Samsung	E788+			x	x	x	x		x					x											
Samsung	E788e			x	x	x	x		x					x											
Samsung	E790			x	x	x	x		x					x											
Samsung	E800			x	x			x	x																
Samsung	E800C			x	x			x	x																
Samsung	E800N			x	x			x	x																
Samsung	E808			x	x			x	x																
Samsung	E810			x	x				x																
Samsung	E810C			x	x				x																
Samsung	E818			x	x				x																
Samsung	E820			x	x			x	x																
Samsung	E820N			x	x			x	x																
Samsung	E820P			x	x			x	x																
Samsung	E820T			x	x			x	x																
Samsung	E830			x	x	x	x		x					x											
Samsung	E838			x	x	x	x		x					x											
Samsung	E840			x	x	x	x		x					x											
Samsung	E848			x	x	x	x		x					x											
Samsung	E850			x	x			x	x																
Samsung	E860V			x	x				x					x											
Samsung	E870			x	x				x					x											
Samsung	E878			x	x				x					x											
Samsung	E880			x	x				x					x											

Samsung	E888			x	x				x					x											
Samsung	E890			x	x	x	x		x					x											
Samsung	E898			x	x	x	x		x					x											
Samsung	E900			x	x	x	x		x					x											
Samsung	E908			x	x				x					x											
Samsung	E910			x	x				x					x											
Samsung	E918			x	x				x					x											
Samsung	E950			x	x	x	x		x					x											
Samsung	E958			x	x	x	x		x					x											
Samsung	F110			x	x	x	x		x					x											
Samsung	F110S			x	x	x	x		x					x											
Samsung	F118			x	x	x	x		x					x											
Samsung	F200			x	x	x	x		x																
Samsung	F210			x	x	x	x		x																
Samsung	F210L			x	x	x	x		x																
Samsung	F218			x	x	x	x		x																
Samsung	F250				x		x		x					x											
Samsung	F250L				x		x		x					x											
Samsung	F258				x		x		x					x											
Samsung	F300				x				x																
Samsung	F300N				x				x																
Samsung	F308				x				x																
Samsung	F310	x			x		x		x					x											
Samsung	F318	x			x		x		x					x											
Samsung	F330	x			x		x		x					x											
Samsung	F330S				x		x		x					x											
Samsung	F338				x		x		x					x											
Samsung	F400	x			x				x																
Samsung	F408	x			x				x																
Samsung	F480	x			x		x		x					x											
Samsung	F480L				x		x		x					x											
Samsung	F480T	x			x		x		x					x											
Samsung	F480V	x			x		x		x					x											
Samsung	F488				x		x		x					x											
Samsung	F488E				x		x		x					x											
Samsung	F490	x			x		x		x					x											
Samsung	F490V	x			x		x		x					x											
Samsung	F500	x			x		x		x					x	x										
Samsung	F508	x			x		x		x					x	x										
Samsung	F700	x			x		x		x					x											
Samsung	F700V	x			x		x		x					x											
Samsung	G400	x			x		x		x					x											
Samsung	G400L	x			x		x		x					x											
Samsung	G408	x			x		x		x					x											
Samsung	G408E				x		x		x					x											
Samsung	G600			x	x	x	x		x					x											
Samsung	G608			x	x	x	x		x					x											
Samsung	G800	x			x		x		x					x											
Samsung	G808	x			x		x		x					x											
Samsung	G808E	x			x		x		x					x											
Samsung	G810	x			x		x		x			x		x											
Samsung	G818E				x		x		x			x		x											
Samsung	I200	x	x				x							x											
Samsung	I450	x			x		x		x		x	x		x	x										
Samsung	I450V	x			x		x		x		x	x		x	x										
Samsung	I458	x			x		x		x		x	x		x	x										
Samsung	I458B	x			x		x		x		x	x		x	x										

Samsung	I520	x			x		x		x		x	x	x	x	x										
Samsung	I520V	x			x		x		x		x	x	x	x	x										
Samsung	I550	x			x		x		x	x	x	x	x	x	x										
Samsung	I550V	x			x		x		x	x	x	x	x	x	x										
Samsung	I550W	x			x		x		x	x	x	x	x	x	x										
Samsung	I560	x			x		x		x	x	x	x	x	x	x										
Samsung	I560V	x			x		x		x	x	x	x	x	x	x										
Samsung	I568	x			x		x		x	x	x	x	x	x	x										
Samsung	I600	x	x			x	x							x											
Samsung	I600V	x	x			x	x							x											
Samsung	I601	x	x			x	x							x											
Samsung	I607	x	x			x	x							x											
Samsung	I608	x	x			x	x							x											
Samsung	I640V	x	x				x							x											
Samsung	I780	x	x				x							x											
Samsung	I780V	x	x				x							x											
Samsung	I788	x	x				x							x											
Samsung	I8510	x			x		x		x	x	x	x	x	x											x
Samsung	I8510C				x		x		x	x	x	x		x											
Samsung	I8510H	x			x		x		x	x	x	x		x											
Samsung	I8510L	x			x		x		x	x	x	x		x											
Samsung	I8510M	x			x		x		x	x	x	x		x											
Samsung	I900	x	x				x							x											
Samsung	I900L	x	x				x							x											
Samsung	I900V	x	x				x							x											
Samsung	I908	x	x				x							x											
Samsung	I908E		x				x							x											
Samsung	J200	x		x	x	x	x		x					x											
Samsung	J208	x		x	x	x	x		x					x											
Samsung	J400	x			x		x		x					x											
Samsung	J408	x			x		x		x					x											
Samsung	J600				x		x		x																
Samsung	J600E				x		x		x																
Samsung	J600G				x		x		x																
Samsung	J600V				x		x		x																
Samsung	J608				x		x		x																
Samsung	J610			x	x	x	x		x					x											
Samsung	J618			x	x	x	x		x					x											
Samsung	J700				x		x		x																
Samsung	J700E				x		x		x																
Samsung	J700L				x		x		x																
Samsung	J700V				x		x		x																
Samsung	J708				x		x		x																
Samsung	J750	x			x		x		x					x											
Samsung	J758	x			x		x		x					x											
Samsung	J800	x			x		x		x					x											
Samsung	J808	x			x		x		x					x											
Samsung	J808E				x		x		x					x											
Samsung	L170	x			x		x		x					x											
Samsung	L310			x	x	x	x		x					x											
Samsung	L600			x	x	x	x		x					x											
Samsung	L608			x	x	x	x		x					x											
Samsung	L700	x			x		x		x					x											
Samsung	L700L				x		x		x					x											
Samsung	L708	x			x		x		x					x											
Samsung	L708E				x		x		x					x											
Samsung	L760	x		x	x	x	x		x					x											

Samsung	L760S	x		x	x	x	x		x					x											
Samsung	L760V	x		x	x	x	x		x					x											
Samsung	L768	x		x	x	x	x		x					x											
Samsung	L770	x			x		x		x					x											
Samsung	L770S	x			x		x		x					x											
Samsung	L770T	x			x		x		x					x											
Samsung	L770V	x			x		x		x					x											
Samsung	L778	x			x		x		x					x											
Samsung	L870	x			x		x		x	x	x	x	x	x											
Samsung	L878	x			x		x		x	x	x	x		x											
Samsung	L878E				x		x		x	x	x	x		x											
Samsung	M110				x		x		x																
Samsung	M118				x		x		x																
Samsung	M120				x		x		x					x	x										
Samsung	M128				x		x		x					x	x										
Samsung	M150			x	x	x	x		x					x											
Samsung	M150N			x	x	x	x		x					x											
Samsung	M158			x	x	x	x		x					x											
Samsung	M300			x	x	x	x		x																
Samsung	M300V			x	x	x	x		x																
Samsung	M310				x				x																
Samsung	M310L				x				x																
Samsung	M310V				x				x																
Samsung	M318				x				x																
Samsung	M3200				x		x		x					x											
Samsung	M3510				x		x		x					x											
Samsung	M3510C				x		x		x					x											
Samsung	M3510L				x		x		x					x											
Samsung	M3518C				x		x		x					x											
Samsung	M600			x	x	x	x		x																
Samsung	M608			x	x	x	x		x																
Samsung	M610				x		x		x					x											
Samsung	M618				x		x		x					x											
Samsung	M620				x		x		x					x											
Samsung	M628				x		x		x					x											
Samsung	M7500	x			x		x		x					x											
Samsung	M7500C				x		x		x					x											
Samsung	M8800	x			x				x					x											
Samsung	M8800B	x			x				x					x											
Samsung	M8800C				x				x					x											
Samsung	M8800H	x			x				x					x											
Samsung	M8800L	x			x				x					x											
Samsung	P100			x	x				x																
Samsung	P107			x	x				x																
Samsung	P108			x	x				x																
Samsung	P200			x	x	x	x		x					x											
Samsung	P207			x	x				x																
Samsung	P300			x	x				x					x											
Samsung	P308			x	x				x					x											
Samsung	P310				x				x					x											
Samsung	P318				x				x					x											
Samsung	P400			x	x				x																
Samsung	P400T			x	x				x																
Samsung	P400V			x	x				x																
Samsung	P408			x	x				x																
Samsung	P408+			x	x				x																
Samsung	P510			x	x				x																

Samsung	P518			x	x				x																
Samsung	P520				x		x		x																
Samsung	P528				x		x		x																
Samsung	P730			x	x				x																
Samsung	P730C			x	x				x																
Samsung	P735			x	x				x																
Samsung	P738			x	x				x																
Samsung	P850			x	x				x					x											
Samsung	P850C			x	x				x					x											
Samsung	P850S			x	x				x					x											
Samsung	P858			x	x				x					x											
Samsung	P900			x	x				x					x											
Samsung	P930	x		x	x	x	x		x					x											
Samsung	S300M			x	x				x																
Samsung	S3030				x		x		x					x											
Samsung	S3030C				x		x		x					x											
Samsung	S3030Q				x		x		x					x											
Samsung	S3600			x	x	x	x		x					x											
Samsung	S3600C			x	x	x	x		x					x											
Samsung	S3600H			x	x	x	x		x					x											
Samsung	S7220	x			x				x					x											
Samsung	S7220C				x				x					x											
Samsung	S7220U	x			x				x					x											
Samsung	S7330	x			x		x		x					x											
Samsung	S8300	x			x				x					x											
Samsung	S8300C				x				x					x											
Samsung	S8300H	x			x				x					x											
Samsung	S8300T	x			x				x					x											
Samsung	S8300V	x			x				x					x											
Samsung	T419				x				x																
Samsung	T519				x		x		x					x											
Samsung	T809			x	x				x					x											
Samsung	U100				x		x		x					x											
Samsung	U108				x		x		x					x											
Samsung	U300				x		x		x					x											
Samsung	U308				x		x		x					x											
Samsung	U600			x	x	x	x		x					x											
Samsung	U608			x	x	x	x		x					x											
Samsung	U700	x		x	x	x	x		x					x											
Samsung	U700V	x		x	x	x	x		x					x											
Samsung	U708	x		x	x	x	x		x					x											
Samsung	U708E	x		x	x	x	x		x					x											
Samsung	U800	x			x		x		x					x											
Samsung	U800E				x		x		x					x											
Samsung	U800V	x			x		x		x					x											
Samsung	U808	x			x		x		x					x											
Samsung	U808E				x		x		x					x											
Samsung	U900	x			x		x		x					x											
Samsung	U900L	x			x		x		x					x											
Samsung	U900T	x			x		x		x					x											
Samsung	U900V	x			x		x		x					x											
Samsung	U908	x			x		x		x					x											
Samsung	U908E	x			x		x		x					x											
Samsung	V200			x	x				x																
Samsung	V200C			x	x				x																
Samsung	V205			x	x				x																
Samsung	V206			x	x				x																

Samsung	V208			x	x				x																
Samsung	V820L	x			x				x																
Samsung	X100			x	x				x																
Samsung	X100A			x	x				x																
Samsung	X105			x	x				x																
Samsung	X108			x	x				x																
Samsung	X120			x	x				x																
Samsung	X140			x	x				x																
Samsung	X148			x	x				x																
Samsung	X160			x	x				x																
Samsung	X160L			x	x				x																
Samsung	X166			x	x				x																
Samsung	X168			x	x				x																
Samsung	X200			x	x				x																
Samsung	X208			x	x				x																
Samsung	X210			x	x				x																
Samsung	X218			x	x				x																
Samsung	X300			x	x				x																
Samsung	X308			x	x				x																
Samsung	X430			x	x				x																
Samsung	X450			x	x				x																
Samsung	X458			x	x				x																
Samsung	X460			x	x			x	x																
Samsung	X460C			x	x			x	x																
Samsung	X461			x	x			x	x																
Samsung	X466			x	x			x	x																
Samsung	X468			x	x			x	x																
Samsung	X468+			x	x			x	x																
Samsung	X480			x	x				x																
Samsung	X480C			x	x				x																
Samsung	X480L			x	x				x																
Samsung	X481			x	x				x																
Samsung	X486			x	x				x																
Samsung	X488			x	x				x																
Samsung	X490			x	x				x																
Samsung	X495			x	x				x																
Samsung	X495H			x	x				x																
Samsung	X496			x	x				x																
Samsung	X497			x	x				x																
Samsung	X500				x				x																
Samsung	X506				x				x																
Samsung	X507				x				x																
Samsung	X508				x				x																
Samsung	X510			x	x				x																
Samsung	X510V			x	x				x																
Samsung	X518			x	x				x																
Samsung	X520			x	x				x																
Samsung	X526			x	x				x																
Samsung	X528			x	x				x																
Samsung	X530			x	x				x																
Samsung	X540			x	x	x	x		x																
Samsung	X550			x	x				x																
Samsung	X550V			x	x				x																
Samsung	X560				x				x																
Samsung	X560L				x				x																
Samsung	X568				x				x																
Samsung	X600			x	x			x	x																

Samsung	X600A			x	x			x	x																
Samsung	X608			x	x			x	x																
Samsung	X610			x	x				x																
Samsung	X620			x	x				x																
Samsung	X628			x	x				x																
Samsung	X630			x	x	x	x		x																
Samsung	X636			x	x	x	x		x																
Samsung	X638			x	x	x	x		x																
Samsung	X640			x	x				x																
Samsung	X640C			x	x				x																
Samsung	X640S			x	x				x																
Samsung	X648			x	x				x																
Samsung	X650			x	x				x																
Samsung	X656			x	x				x																
Samsung	X658			x	x				x																
Samsung	X660			x	x				x					x											
Samsung	X668			x	x				x					x											
Samsung	X670				x				x																
Samsung	X678				x				x																
Samsung	X680				x				x																
Samsung	X680V				x				x																
Samsung	X686				x				x																
Samsung	X688				x				x																
Samsung	X700			x	x				x																
Samsung	X700N			x	x				x																
Samsung	X708			x	x				x																
Samsung	X710			x	x				x																
Samsung	X718			x	x				x																
Samsung	X800			x	x				x					x											
Samsung	X808			x	x				x					x											
Samsung	X810			x	x				x					x											
Samsung	X818			x	x				x					x											
Samsung	X820			x	x				x					x											
Samsung	X828			x	x				x					x											
Samsung	X830			x	x				x																
Samsung	X836				x				x																
Samsung	X838			x	x				x																
Samsung	Z105	x			x				x																
Samsung	Z105M	x			x				x																
Samsung	Z105T	x			x				x																
Samsung	Z105U	x			x				x																
Samsung	Z107	x			x				x																
Samsung	Z107M	x			x				x																
Samsung	Z107V	x			x				x																
Samsung	Z130	x			x		x		x																
Samsung	Z140	x			x				x					x											
Samsung	Z140M	x			x				x					x											
Samsung	Z140N	x			x				x					x											
Samsung	Z140V	x			x				x					x											
Samsung	Z150	x			x		x		x																
Samsung	Z170	x			x		x		x					x											
Samsung	Z230	x			x		x		x																
Samsung	Z238	x			x				x																
Samsung	Z240	x			x		x		x																
Samsung	Z240E	x			x		x		x																
Samsung	Z248	x			x		x		x																
Samsung	Z300	x			x				x					x											

Samsung	Z300M	x			x				x					x											
Samsung	Z308	x			x				x					x											
Samsung	Z370	x			x				x					x											
Samsung	Z400	x		x	x	x	x		x					x											
Samsung	Z400V	x		x	x	x	x		x					x											
Samsung	Z500	x			x				x																
Samsung	Z500V	x			x				x																
Samsung	Z508	x			x				x																
Samsung	Z510	x			x		x		x					x											
Samsung	Z540	x			x		x		x					x											
Samsung	Z540V	x			x		x		x					x											
Samsung	Z548	x			x				x					x											
Samsung	Z560	x			x				x																
Samsung	Z560V	x			x				x																
Samsung	Z630	x			x				x					x											
Samsung	Z710	x			x		x		x					x											
Samsung	Z720	x			x		x		x					x											
Samsung	Z720M	x			x		x		x					x											
Samsung	Z720V	x			x		x		x					x											
Samsung	Z728	x			x		x		x					x											
Samsung	ZM60	x			x				x					x											
Samsung	ZV40	x		x	x				x					x											
Samsung	ZV60	x			x		x		x					x											
Sendo	M570			x	x			x	x																
Sendo	M571			x	x			x	x																
Sendo	P600			x	x			x	x																
Sendo	P601			x	x			x	x																
Sendo	S600			x	x			x	x																
Sendo	S601			x	x			x	x																
Sendo	SV663			x	x			x	x																
Sendo	X			x	x	x	x	x	x					x											
Sharp	TM100			x	x				x																
Sharp	TM200			x	x				x					x											
Sharp	V802SH	x			x				x					x											
Siemens	2128			x	x																				
Siemens	3618			x	x																				
Siemens	A31			x	x			x	x																
Siemens	A50			x																					
Siemens	A55			x																					
Siemens	A56			x																					
Siemens	A57			x																					
Siemens	A60			x	x																				
Siemens	A62			x	x																				
Siemens	A65			x	x																				
Siemens	A75			x	x																				
Siemens	A76			x	x																				
Siemens	AF51			x	x			x	x																
Siemens	AL21			x	x			x	x																
Siemens	AL21a			x	x			x	x																
Siemens	AP75			x	x			x	x																
Siemens	AP75a			x	x			x	x																
Siemens	AX72			x	x			x	x																
Siemens	AX75			x	x			x	x																
Siemens	AX76			x	x			x	x																
Siemens	C45			x																					
Siemens	C55			x	x																				
Siemens	C56			x	x																				

Siemens	C60			x	x																				
Siemens	C62			x	x			x	x																
Siemens	C65			x	x			x	x			x													
Siemens	C66			x	x			x	x																
Siemens	C70			x	x			x	x																
Siemens	C71			x	x			x	x																
Siemens	C71a			x	x			x	x																
Siemens	C72			x	x			x	x																
Siemens	C75			x	x	x	x	x	x					x											
Siemens	C75V			x	x	x	x	x	x					x											
Siemens	CF110			x	x																				
Siemens	CF62			x	x																				
Siemens	CF62T			x	x																				
Siemens	CF63			x	x																				
Siemens	CF75			x	x	x	x	x	x			x		x											
Siemens	CF76			x	x			x	x			x		x											
Siemens	CFX65			x	x			x	x																
Siemens	CL75			x	x			x	x																
Siemens	CT65			x	x			x	x			x													
Siemens	CT70			x	x			x	x																
Siemens	CT71			x	x			x	x																
Siemens	CV65			x	x			x	x			x													
Siemens	CV70			x	x			x	x																
Siemens	CV71			x	x			x	x																
Siemens	CX65			x	x			x	x			x		x											
Siemens	CX70			x	x			x	x			x		x											
Siemens	CX70E			x	x			x	x			x		x											
Siemens	CX75			x	x			x	x			x		x											
Siemens	CXI70			x	x			x	x			x		x											
Siemens	CXO65			x	x			x	x			x		x											
Siemens	CXT65			x	x			x	x			x		x											
Siemens	CXT70			x	x			x	x			x		x											
Siemens	CXV65			x	x			x	x			x		x											
Siemens	CXV70			x	x			x	x			x		x											
Siemens	M50			x	x																				
Siemens	M55			x	x																				
Siemens	M56			x	x																				
Siemens	M65			x	x	x	x	x	x			x		x											
Siemens	M65V			x	x	x	x	x	x			x		x											
Siemens	M75			x	x			x	x																
Siemens	MC60			x	x																				
Siemens	MCT62			x	x																				
Siemens	ME45			x	x																				
Siemens	ME75			x	x			x	x					x											
Siemens	MT50			x	x																				
Siemens	S45			x	x																				
Siemens	S46			x	x																				
Siemens	S55			x	x																				
Siemens	S56			x	x																				
Siemens	S57			x	x																				
Siemens	S65			x	x			x	x			x		x											
Siemens	S66			x	x			x	x					x											
Siemens	S75			x	x	x	x	x	x				x	x	x										
Siemens	SF65			x	x			x	x																
Siemens	SK65			x	x			x	x			x		x											
Siemens	SL42			x																					
Siemens	SL55			x	x																				

Siemens	SL56			x	x																			
Siemens	SL65			x	x			x	x			x		x										
Siemens	SL75			x	x	x	x	x	x					x	x									
Siemens	SP65			x	x	x	x	x	x					x										
Siemens	ST55			x	x			x	x															
Siemens	SX1			x	x	x	x	x	x	x		x		x										
Siemens	U15	x		x	x			x	x															
Skyspring	SP-770				x				x															
Song	A168			x	x			x	x															
Sony Ericsson	C510	x			x		x		x															
Sony Ericsson	C510a	x			x		x		x															
Sony Ericsson	C510c	x			x		x		x															
Sony Ericsson	C702	x		x	x	x	x	x	x		x	x		x	x									
Sony Ericsson	C702c			x	x	x	x	x	x		x	x		x	x									
Sony Ericsson	C902	x		x	x	x	x	x	x		x	x	x	x	x									
Sony Ericsson	C902c			x	x	x	x	x	x		x	x		x	x									
Sony Ericsson	C905	x		x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	C905a	x		x	x	x	x	x	x		x	x		x										
Sony Ericsson	C905c			x	x	x	x	x	x		x	x		x										
Sony Ericsson	D750i			x	x	x	x	x	x	x		x		x	x									
Sony Ericsson	F305			x	x	x	x	x	x															
Sony Ericsson	F500i			x	x	x	x	x	x	x				x										
Sony Ericsson	G502	x		x	x	x	x	x	x		x	x		x	x									
Sony Ericsson	G502c			x	x	x	x	x	x		x	x		x	x									
Sony Ericsson	G700	x		x	x	x	x	x	x			x		x										
Sony Ericsson	G700b	x		x	x	x	x	x	x			x		x										
Sony Ericsson	G700c			x	x	x	x	x	x			x		x										
Sony Ericsson	G705	x		x	x	x	x	x	x		x	x		x										
Sony Ericsson	G705a	x		x	x	x	x	x	x		x	x		x										
Sony Ericsson	G705u	x		x	x	x	x	x	x		x	x		x										
Sony Ericsson	G900	x		x	x	x	x	x	x			x		x										
Sony Ericsson	G900c			x	x	x	x	x	x			x		x										
Sony Ericsson	J200c			x	x	x	x			x														
Sony Ericsson	J200i			x	x	x	x			x														
Sony Ericsson	J210c			x	x	x	x	x	x	x														
Sony Ericsson	J210i			x	x	x	x	x	x	x														
Sony Ericsson	J220a			x	x	x	x	x	x	x														
Sony Ericsson	J220c			x	x	x	x	x	x	x														
Sony Ericsson	J220i			x	x	x	x	x	x	x														
Sony Ericsson	J230a			x	x	x	x	x	x	x														
Sony Ericsson	J230c			x	x	x	x	x	x	x														
Sony Ericsson	J230i			x	x	x	x	x	x	x														
Sony Ericsson	J300a			x	x	x	x	x	x	x		x		x										
Sony Ericsson	J300c			x	x	x	x	x	x	x		x		x										
Sony Ericsson	J300i			x	x	x	x	x	x	x		x		x										
Sony Ericsson	K200a				x				x															
Sony Ericsson	K200c				x				x															
Sony Ericsson	K200i				x				x															
Sony Ericsson	K220c				x				x															
Sony Ericsson	K220i				x				x															
Sony Ericsson	K300a			x	x	x	x	x	x	x		x		x										
Sony Ericsson	K300c			x	x	x	x	x	x	x		x		x										
Sony Ericsson	K300i			x	x	x	x	x	x	x		x		x										
Sony Ericsson	K310a			x	x	x	x	x	x		x	x	x											
Sony Ericsson	K310c			x	x	x	x	x	x		x	x	x											
Sony Ericsson	K310i			x	x	x	x	x	x		x	x	x											
Sony Ericsson	K320i			x	x	x	x	x	x			x	x	x										

Sony Ericsson	K330				x				x																
Sony Ericsson	K330a				x				x																
Sony Ericsson	K500c			x	x	x	x	x	x	x		x		x											
Sony Ericsson	K500i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	K506c			x	x	x	x	x	x	x		x		x											
Sony Ericsson	K508c			x	x	x	x	x	x	x		x		x											
Sony Ericsson	K508i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	K510a			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K510c			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K510i			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K530c	x		x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	K530i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K550c				x		x		x	x	x	x	x	x	x										
Sony Ericsson	K550i				x		x		x	x	x	x	x	x	x										
Sony Ericsson	K600i	x		x	x	x	x	x	x	x		x		x											
Sony Ericsson	K608i	x		x	x	x	x	x	x	x		x		x											
Sony Ericsson	K610c	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K610i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K618i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K630i	x		x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	K660i	x		x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	K700c			x	x	x	x	x	x	x		x		x											
Sony Ericsson	K700i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	K750c			x	x	x	x	x	x	x	x	x		x	x										
Sony Ericsson	K750i			x	x	x	x	x	x	x	x	x		x	x										
Sony Ericsson	K758c			x	x	x	x	x	x	x		x		x	x										
Sony Ericsson	K770i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K790a			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	K790c			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K790i			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K800c	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K800i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K810i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	K818c			x	x	x	x	x	x	x		x	x	x											
Sony Ericsson	K850a	x			x		x		x	x	x	x	x	x	x										
Sony Ericsson	K850i	x			x		x		x	x	x	x	x	x	x										
Sony Ericsson	K858c				x		x		x	x	x	x	x	x	x										
Sony Ericsson	M600c	x			x		x		x	x		x		x	x										
Sony Ericsson	M600i	x			x		x		x	x		x		x	x										
Sony Ericsson	M608c				x		x		x	x		x		x	x										
Sony Ericsson	P1c				x		x		x	x		x		x											
Sony Ericsson	P1i	x			x		x		x	x		x		x											
Sony Ericsson	P800			x	x	x	x	x	x	x		x		x											
Sony Ericsson	P802			x	x	x	x	x	x	x		x		x											
Sony Ericsson	P900			x	x	x	x	x	x	x		x		x											
Sony Ericsson	P908			x	x	x	x	x	x	x		x		x											
Sony Ericsson	P910a			x	x	x	x	x	x	x		x		x											
Sony Ericsson	P910c	x		x	x	x	x	x	x	x		x		x											
Sony Ericsson	P910i	x		x	x	x	x	x	x	x		x		x											
Sony Ericsson	P990i	x			x		x		x	x		x		x	x										
Sony Ericsson	R300				x				x																
Sony Ericsson	R300a				x				x																
Sony Ericsson	R306				x				x																
Sony Ericsson	R306a				x				x																
Sony Ericsson	S302				x		x																		
Sony Ericsson	S500c			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	S500i			x	x	x	x	x	x	x	x	x	x	x	x										

Sony Ericsson	S700c			x	x	x	x	x	x	x		x		x											
Sony Ericsson	S700i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	S710a			x	x	x	x	x	x	x				x											
Sony Ericsson	T100			x						x															
Sony Ericsson	T102			x						x															
Sony Ericsson	T105			x						x															
Sony Ericsson	T106			x						x															
Sony Ericsson	T200			x	x					x															
Sony Ericsson	T202			x	x					x															
Sony Ericsson	T226			x	x	x	x	x	x	x				x											
Sony Ericsson	T226m			x	x	x	x	x	x	x															
Sony Ericsson	T226s			x	x	x	x	x	x	x				x											
Sony Ericsson	T230			x	x	x	x	x	x	x				x											
Sony Ericsson	T237			x	x	x	x	x	x	x															
Sony Ericsson	T237s			x	x	x	x	x	x	x															
Sony Ericsson	T238			x	x	x	x	x	x	x				x											
Sony Ericsson	T250a				x				x																
Sony Ericsson	T250i				x				x																
Sony Ericsson	T258c				x				x																
Sony Ericsson	T280a				x				x																
Sony Ericsson	T280i				x				x																
Sony Ericsson	T290a			x	x	x	x	x	x	x															
Sony Ericsson	T290c			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T290i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T292a			x	x	x	x	x	x	x															
Sony Ericsson	T300			x	x	x	x	x	x	x				x											
Sony Ericsson	T303				x				x																
Sony Ericsson	T303a				x				x																
Sony Ericsson	T303c				x				x																
Sony Ericsson	T306			x	x	x	x	x	x	x				x											
Sony Ericsson	T310			x	x	x	x	x	x	x				x											
Sony Ericsson	T312			x	x	x	x	x	x	x				x											
Sony Ericsson	T316			x	x	x	x	x	x	x															
Sony Ericsson	T600			x						x															
Sony Ericsson	T602			x						x															
Sony Ericsson	T610			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T616			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T618			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T628			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T630			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T637			x	x	x	x	x	x	x															
Sony Ericsson	T650i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	T658c	x		x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	T68i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T68ie			x	x	x	x	x	x	x		x		x											
Sony Ericsson	T700	x		x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	V600i	x		x	x	x	x	x	x	x		x		x	x										
Sony Ericsson	V630i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	V640i	x		x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	V800	x		x	x	x	x	x	x	x		x		x	x										
Sony Ericsson	W200a			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W200c			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W200i			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W300c			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	W300i			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	W302			x	x	x	x																		
Sony Ericsson	W350a				x		x		x																

Sony Ericsson	W350c				x		x		x																
Sony Ericsson	W350i				x		x		x																
Sony Ericsson	W380a				x		x		x			x		x											
Sony Ericsson	W380i				x		x		x		x	x	x	x											
Sony Ericsson	W550c			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W550i			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W580a			x	x	x	x	x	x	x		x		x											
Sony Ericsson	W580c			x	x	x	x	x	x	x		x	x	x											
Sony Ericsson	W580i			x	x	x	x	x	x	x		x	x	x											
Sony Ericsson	W595	x		x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	W595a			x	x	x	x	x	x		x	x		x	x										
Sony Ericsson	W595c	x		x	x	x	x	x	x		x	x		x	x										
Sony Ericsson	W595s			x	x	x	x	x	x		x	x		x	x										
Sony Ericsson	W600c			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	W600i			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	W610c			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W610i			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W660c	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W660i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W700c			x	x	x	x	x	x	x		x		x	x										
Sony Ericsson	W700i			x	x	x	x	x	x	x		x		x	x										
Sony Ericsson	W710c			x	x	x	x	x	x	x	x	x	x	x											
Sony Ericsson	W710i			x	x	x	x	x	x	x	x	x	x	x											
Sony Ericsson	W712a			x	x	x	x	x	x	x		x		x											
Sony Ericsson	W760a	x		x	x	x	x	x	x		x	x		x	x										
Sony Ericsson	W760c			x	x	x	x	x	x		x	x		x	x										
Sony Ericsson	W760i	x		x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	W800c			x	x	x	x	x	x		x	x		x	x										
Sony Ericsson	W800i			x	x	x	x	x	x		x	x		x	x										
Sony Ericsson	W810c			x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	W810i			x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	W830c			x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	W830i			x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	W850c	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W850i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W880i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W888c			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W890i	x		x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	W900c	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W900i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	W902	x		x	x	x	x	x	x		x	x	x	x											
Sony Ericsson	W908c	x			x		x		x	x	x	x	x	x	x										
Sony Ericsson	W910i	x			x		x		x	x	x	x	x	x	x										
Sony Ericsson	W950i	x			x		x		x	x		x		x											
Sony Ericsson	W958c				x		x		x	x		x		x											
Sony Ericsson	W960i	x		x	x	x	x	x	x	x		x		x											
Sony Ericsson	W980	x		x	x	x	x	x	x		x	x	x	x	x										
Sony Ericsson	X1a	x	x				x							x											
Sony Ericsson	X1i	x	x				x							x											
Sony Ericsson	Z1010	x		x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z200			x	x					x															
Sony Ericsson	Z208			x	x					x															
Sony Ericsson	Z250a				x				x																
Sony Ericsson	Z250i				x				x																
Sony Ericsson	Z258c				x				x																
Sony Ericsson	Z300a			x	x	x	x	x	x	x															
Sony Ericsson	Z300c			x	x	x	x	x	x	x															

Sony Ericsson	Z300i			x	x	x	x	x	x	x															
Sony Ericsson	Z310a				x		x		x	x		x	x	x	x										
Sony Ericsson	Z310c				x		x		x	x		x	x	x	x										
Sony Ericsson	Z310i				x		x		x	x		x	x	x	x										
Sony Ericsson	Z320a				x				x																
Sony Ericsson	Z320c				x				x																
Sony Ericsson	Z320i				x				x																
Sony Ericsson	Z500a			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z500c			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z500i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z502a			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z505a			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z520a			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z520c			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z520i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z525a			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z525i			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z530c			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	Z530i			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	Z550a			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	Z550c			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	Z550i			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	Z555a				x		x		x			x		x											
Sony Ericsson	Z555i				x		x		x		x	x	x	x											
Sony Ericsson	Z558c			x	x	x	x	x	x	x		x	x	x											
Sony Ericsson	Z558i			x	x	x	x	x	x	x		x	x	x											
Sony Ericsson	Z600			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z608			x	x	x	x	x	x	x		x		x											
Sony Ericsson	Z610i	x		x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	Z710c			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	Z710i			x	x	x	x	x	x	x	x	x	x	x	x										
Sony Ericsson	Z712a			x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	Z750a	x		x	x	x	x	x	x	x		x		x	x										
Sony Ericsson	Z750i	x		x	x	x	x	x	x	x		x	x	x	x										
Sony Ericsson	Z770i	x			x		x		x	x		x		x	x										
Sony Ericsson	Z800i	x		x	x	x	x	x	x	x		x		x	x										
Spice	D80				x				x																
Spice	S650				x				x																
Spice	S707				x				x																
Spice	S920				x				x																
TCL	738			x	x																				
TCL	766			x	x			x	x																
TCL	3588			x	x																				
TCL	Q550			x	x																				
Tecom	F5			x	x			x	x	x															
TelMe	T918			x	x			x	x																
Toshiba	G500	x	x				x							x											
Toshiba	G710		x				x							x											
Toshiba	G900	x	x				x							x											
Toshiba	TS803	x			x				x			x		x	x										
Toshiba	TS921	x		x	x				x																
Toshiba	V830T	x			x				x			x		x	x										
Toshiba	V902T	x		x	x				x																
Toshiba	V903T	x			x				x																
Venko	Amigo				x				x																
Venko	Amigo850				x				x																
Vertu	AscentTi	x			x		x		x					x											

VK Mobile	VK1500				x																			
VK Mobile	VK180				x				x	x														
VK Mobile	VK2010				x				x															
VK Mobile	VK2030			x	x			x	x															
VK Mobile	VK2200				x				x															
VK Mobile	VK4000				x				x															
Voxtel	V310				x				x															
Xcute	DV1			x	x				x															
Zeason	M200			x	x			x	x															
Zeason	S100			x	x																			